

# T68 GEN5 USER MANUAL

## Introduction

Thank you for using RAP4 products. T68 Gen5 is a .68 cal patented dual-feed paintball marker, which uses .68 paintballs and provides the advanced and professional paintball marker system to all users. The T68 Gen5 can be used with magazine or with hopper.

## Warning

### THE USER MUST READ THIS MANUAL PRIOR TO USE OF THESE PRODUCTS.

Handle and operate this product with care to avoid any injury.

Copyright is reserved. RAP4 products are patented. All patented items have legal protection and any unauthorized copy will be prosecuted to the fullest extent of the law.

1. This marker is intended for shooting paintballs unless otherwise labeled.
2. This marker must be used by adults of 18 years or older only.
3. Read the manual completely before using this product.
4. This marker is not a toy. It can cause injury to persons, animal or objects nearby.
5. Goggles and masks for eyes and skin protection must be worn at all times during operation, assemble, cleaning and maintenance on this product.
6. Do not point or fire the marker at any human, animal and object. Do not point or fire the marker at anyone that does not have the appropriate head, throat, eyes and body protection.
7. This marker should only be used at a licensed and insured paintball field or designated training center. When using this product, obey all local laws and your country of operation. If you are not sure, call the non emergency phone number listed for your local police department,
8. Looking into the muzzle and bore is prohibited under any conditions.
9. Be aware of unexpected human beings and animals intruding into the shooting area. "Clearing the shooting area" before using the marker is mandatory.
10. Keeping this product safely stored away from children. This is mandatory when storing the paintballs, cylinders, cartridges, marker and the relevant equipment.
11. Packing the marker into a suitable carrying case is mandatory during transportation.
12. When performing maintenance or repairing the marker, the battery power must be turned off and magazine, cylinder / cartridge must be removed. Magazine spring release switch must be pushed to release forwarder. Magazine must not be loaded during maintenance or repair.
13. Remove the cylinder or cartridge; install a plug in the barrel and magazine, release the charging handle and unload the paintballs is required when the marker is not in use.
14. Always keep your finger or any objects away from the trigger assembly when the marker is not in the firing condition.
15. It is prohibited to modify, convert or transform this product under any condition. Unless noted otherwise, professional repair or maintenance must be performed by a qualified technician.
16. Do not damage the high pressure tube. The high pressure tube can be damaged by striking or gashing. Discontinue use if damaged as this may cause injury.
17. Unauthorized modification or conversion of any air pressure regulator part is prohibited.
18. Do not damage or modify any part of this product.
19. Handle with care when using this product, all parts of the gun can cause injury if improperly used.
20. Do not fire the marker to at any distance less than 25 feet or serious injury may result.
21. Over tighten any screws will cause the thread destroyed.
22. The cylinders are not a part of this product. Real Action Paintball Inc. (RAP4) is not responsible for any cylinder qualities.
23. RAP4 company is not responsible for any damage or personal injury when any part of the high pressure tube, tube connector or the relevant air pressure system is removed or loosen or turned.

## How to assemble?

1. Inspect the package content before assembly! The package content varies depending on model.



2. Install the barrel and lock the screws.



3. Install the feeder if you want to use hopper or install the feed port cover if you want to use magazines only.



4. Insert the braided air hose adaptor or the remote line adaptor (optional) on the receiver.



5. Connect a CO<sub>2</sub> or compressed air tank to the marker, pull the charging lever back to cock the marker, and dry fire a few times to make sure the marker functions normally.



6. After test firing, put on a loaded hopper or insert a loaded magazine as showed in the picture, depending on the usage. Then shoot at the target.



7. Adjust the velocity by using the velocity adjusting rod. Be sure to cock the bolt back before making an adjustment.



8. Adjust the collapsible stock to the desired length by depressing the adjusting lever and slide the stock back or forth.



9. Check the rear sight with the windage and elevation dials



10. It is recommended that the user inspects all the screws for tightness after use.

## How to perform maintenance?

1. Unload the feeder and the carrying handle.



2. Push the magazine release button to remove the magazine; uninstall the magazine well.



3. Dismount the butt stock by removing the anchoring screws and remove the lower receiver.



4. Loosen the anchoring screws of the barrel.



5. Separate the left side of the receiver.



6. Use wet tissue or fine cloth to clean all the parts and apply 1 or 2 drops silicon oil to lubricate the parts (as showed in the picture).



7. After finishing the maintenance, reverse the steps above for re-assembly. (Make sure to follow steps 5-7 on the assembly guide.)

Congratulations! You now own a high-end quality paintball marker which, with proper maintenance, will provide many years of enjoyment. Please complete and return this form, along with a copy of your purchase receipt, within 15 days of purchase so that we may validate your one year limited warranty:

Mail to:

RAP4 Paintball Marker Registration

5151 Lafayette Street

Santa Clara, CA 95054

USA

MODEL NUMBER: \_\_\_\_\_

SERIAL NUMBER: \_\_\_\_\_

DATE OF PURCHASE: \_\_\_\_\_

PURCHASED FROM: \_\_\_\_\_

NAME: \_\_\_\_\_

ADDRESS: \_\_\_\_\_  
\_\_\_\_\_

PHONE NUMBER: \_\_\_\_\_

EMAIL ADDRESS: \_\_\_\_\_