


# Spyder Aggressor XT



Item #	Name of Parts
1906A	Aggressor XT Receiver (Deep Blue)
1928CA	XT Striker Plug (Deep Blue)
1931U	Aggressor Deluxe Trigger Frame
1935MA	Aggressor XT C/A Adapter (Deep Blue)
19A	Striker O-Ring (#18A/#18B)
20	Barrel O-Ring (Black)
2002A	Aggressor XT Barrel (Green)
2004GA	Aggressor XT Direct Feed (Green)
2006A	Aggressor XT Receiver (Green)
2028CA	XT Striker Plug (Green)
2035MA	Aggressor XT C/A Adapter (Green)
2041	Aggressor Spare Parts Kit
21	Bolt Pin
22	Bolt Screw
22B	M4 x 8 Screw w/Washer-Black
23B	Quick Disconnect Pin
23C	Disconnect Pin Lock
25	Striker Spring
26A	Striker Buffer (#18A/#18B)
27	Striker Spring Guide
27A	Flat Disc
29	Adjust Screw (Black)
33A	45 Grip Frame (33A/33C)
33C	Grip Cover Screw (#33A)
33F	Compact Nut Screw (#36C)
36E	5/32" x 7/8" Screw (Black)
37	Steel Hose
37A	Filter O-Ring
37B	Air Filter
37C	Disconnect O-Ring #011 (Black)
37D	Plastic Washer (Disconnect Hose)
38	Safety Button Set (Large)
38B	Ball Bearing & Spring
39B	Cocking Rod (Silver)
42	Male To Male Adapter
47E	TL Sight Rail w/Beaver Tail (Silver)
48	Trigger Roll Pin (Large)
49	Sear Roll Pin (Medium)
49A	Secondary Sear Roll Pin (small)
54ES	Straight Elbow (Black)
5814	Deluxe Double Trigger (Black)

Item #	Name of Parts
12	Cup Seal
13	Valve Pin
14	Valve Body
15	Valve Body Screw
16A	M5 x 12.5 Screw
2017H	Venturi Cocking Bolt
18A	Deluxe Striker Bolt (#19A)
1902A	Aggressor XT Barrel (Deep Blue)
1904GA	Aggressor XT Direct Feed (Deep Blue)

Item #	Name of Parts
01	Spyder Barrel Plug
04G	Detent Cover (Plastic)
05A	M4 x 6 Screw (#4B,4C,47D) (Silver)
05B	M4 x 6 Screw (#4B,4C,47D) (Black)
05C	Direct Feed Screw (M4 x 8 w/Washer)
2208	REaervoir Plug (Green)
2108	Reservoir Plug (Deep Blue)
09	O-Ring #015 80D
10	Valve Spring (Spyder)
11	Cup Seal Guide