

CO2/HP AIR TANK WARNING

⚠ WARNING

- VALVES MUST BE INSTALLED OR REMOVED ONLY BY QUALIFIED PERSONNEL.
- BOTTLE MUST BE RETESTED SEE CO2/HP TANK LABEL FOR RETEST DATE!
- Improper use, filling, storage or disposal of this cylinder may result in death, personal injury and property damage.
- This cylinder must be filled only by properly Trained personnel in accordance with CGA Pamphlets P.1 and G-6.3 available from the Compressed Gas Association WWW.CGANET.COM
- Do not over pressurize. Do not expose pressurized cylinder to temperatures in excess of 130 degrees F.
- Do not expose cylinder to corrosive materials and do not clean with caustic cleaners.
- Do not alter this cylinder in any way.
- Cylinders heated to a temperature of 250 degrees F or more must be condemned or requalified in accordance with test defined in CFR-49.
- Keep cylinder out of reach of children.
- The valve should NEVER be detached from the canister. Should this occur, please seek assistance from a trained airmith immediately.
- This tank is intended for paintball use only.


SPYDER RODEO

ITEM #	Name of Parts
01	Spyder Barrel Plug
2602	12" Barrel (Silver)
03	Ball Stopper
2604C	Mini Detent Cover (camo)
2604G	Mini Detent Cover (green)
04GA	Mini Detent Cover (black)
05B	M4 x 6 Screw (silver)
2604	Direct Feed (silver)
2606B	Receiver (black)
2606C	Receiver (camo)
2606G	Receiver (green)
2608B	Vertical Adapter with Gauge (black)
2608C	Vertical Adapter with Gauge (camo)
2608G	Vertical Adapter with Gauge (green)
2608LB	Low Pressure Chamber (black)
2608LC	Low Pressure Chamber (camo)
2608LG	Low Pressure Chamber (green)
2608S	Regulator Lock Screw

ITEM #	Name of Parts
09	O-Ring #15 80D
10A	Valve Spring
11	Cup Seal Guide
12	Cup Seal
13	Valve Pin
14	Valve Body
15	Valve Body Screw
16D	M5 x 12 Screw (silver)
2617B	Venturi Cocking Bolt (black)
2617C	Venturi Cocking Bolt (camo)
2617	Venturi Cocking Bolt (green)
18B	Striker bolt
19A	Striker O-Ring
20	Barrel O-Ring (black)
21	Bolt Pin
22	Bolt Screw
23B	Quick Disconnect Pin
23C	Disconnect Pin Lock

ITEM #	Name of Parts
24A	Sight Rail Screw
25	Striker Spring
26A	Striker Buffer
27	Striker Spring Guide
27A	Flat Disc
2628	Striker Bolt Plug (silver)
29B	Lock Screw
RF29	Thumb Adjuster w/ screw
2631	Deluxe Trigger Frame (silver)
2631C	Deluxe Trigger Frame (black)
31B	Sear
32E	45 Grip Cover
33C	Grip Cover Screws (M3 x 10)
33F	Nut Screw
2635B	C/A Adapter (black)
2635C	C/A Adapter (camo)
2635G	C/A Adapter (green)
2635	Deluxe Drop Forward (silver)
35E	Regulator Adjust Screw

ITEM #	Name of Parts
2644B	Expansion Chamber (black)
2644C	Expansion Chamber (camo)
2644G	Expansion Chamber (green)
2647	Sight Rail w/Beaver Tail (silver)
48	Trigger Roll Pin (Large)
49	Sear Roll Pin (Medium)
49A	Secondary Sear Roll Pin
5814	Double Trigger (black)



ITEM #	Name of Parts
36D	5/32" x 5/8" Screw
36E	5/32" x 7/8" Screw
37A	Filter O-Ring
37B	Air Filter
37C	Disconnect O-Ring #011 (Black)
37D	Plastic Washer
2637B	Disconnect Hose (black)
2637C	Disconnect Hose (camo)
2637G	Disconnect Hose (green)
2641	Spare Parts Kit
38A	Safety Button Set
38B	Ball Bearing & Spring
42F	M8 x M8 Adapter
2644B	Expansion Chamber (black)
2644C	Expansion Chamber (camo)
2644G	Expansion Chamber (green)
2647	Sight Rail w/Beaver Tail (silver)
48	Trigger Roll Pin (Large)
49	Sear Roll Pin (Medium)
49A	Secondary Sear Roll Pin
5814	Double Trigger (black)